

1. Peel the protective liner off of the the gasket surface and place the CoverWell on a flat dry surface GASKET SIDE UP. Aliquot reagent onto the chamber surface. Chambers may be used completely filled or with a volume selected for the size specimen you are using.
2. Place a microscope slide or cover slip above the chamber surface. Lower to make contact with the gasket.
3. Press gently but firmly on the GLASS to seal.

*CoverWell™ Incubation Chambers are intended for laboratory use only.*