

1. Peel the protective liner off of the gasket surface and place the CoverWell on a flat dry surface GASKET SIDE UP. Aliquot a small amount of mounting medium onto the chamber surface. Place the specimen into the medium and fill the remaining chamber area with additional medium.
2. Place a microscope slide or cover slip above the chamber surface. Lower to make contact with the gasket.
3. Press gently but firmly on the GLASS to seal.

*CoverWells Imaging Chambers are intended for laboratory use only.*