

1. Peel the protective liner off the gasket surface.
2. Press the gasket surface onto the glass coverslip or the microscope slide. Surfaces may be wet or dry.
3. Press gently but firmly to form a secure seal.
4. Add or remove reagents by pipetting through the access ports in the chamber surface.
5. To remove – simply peel off. Chambers may be rinsed and reused.

*CoverWell™ Perfusion Chambers are intended for laboratory use only.*